



KPT81067

LOI21 KPT81067 Pull-out Spout Kitchen Faucet **Installation Instructions**

Tools and Materials



Names of Component




NO	NAME
Α	Flange Cover
В	Angle Stop Valve
С	Weight
D	Spray Hose
Е	Faucet
F	Braided Hoses(F1,F2)
G	Washer
Н	Rubber Washer
ı	Brass Washer
J	Fixing Screw
K	Spray Outlet Tube

Installation Process

(1)


Install (B) into (A), then apply pipe sealant to threads on (B) (photo I.) Tighten (B) and (A) to water supply hose with an wrench(photo II)



(2)

Loosen (G), (H), (I),(J) by order.(photo I)


Place (E) on the place where deck been drilled, install



Installation Process

Install (F1,F2) on angle stop valve (B), then tighten hex nut with a wrench.

(F1) connect to hot water supply, and (F2) connect to cold water supply.



(4)


Connect (D) on spray outlet tube (K), then tighten hex nut with a wrench.(photo I)

Install (C) on (D) by phillips screwdriver. (photo II)

NOTE:

You can adjust the extendable length of the spray hose.


Install the weight at the desired position, and Tighten securely, but do not over tighten.



(5)

Installation finished.

(Release the stopping water rivet of angle stop valve B.)



Usage instruction

(1) Handle be pull forward- dispensing water on Handle be push backdispensing water off Pull to the right- cold water Pull to the left- hot water (2)Pull out the spout

Hold the pullout spout and pull forward to you. OPEN Pullout spout CLOSE

Maintain and Cleaning

It gives you far more flexibility.

- (1) Day to day basis: Drying our faucets with a soft cloth immediately after using them.
- (2) Spraying our faucets with mild cleaner (PH value = 7), followed by cleaning them with water then drying them with a dried-soft cloth.
- (3) Aerator which be installed at spout of faucet should be taken off and cleaned in case mineral deposits blocked the filtered net. It will cause the volume of water given decreased.

