classic®

SNP1655H
Installation Instructions

Tools and Materials



Names of Component



NO	NAME
A	Flange Cover
B	Check Valve with Stopping Water Rivet
B1	Packing
C	Faucet (Mixer body)
D	Bracket of Hand Shower
E	Hand Shower Hose
F	Filtered Net Packing
G	Hand Shower
V	Packing

Installation process

(1)
Install B into A, then apply pipe sealant to threads on B (photo I) Wrenched B + A to water supply hose (photo II)



photo I



photo II

(2)
Install B1 into hot and cold inlets (C1), which located in the rear of faucet body C. Then, wrench C1 to B and make sure the faucet body C is stabilized on B (photo I.)



photo I


photo II

(3)
Insert V into shower hose E, then wrench it on C. Then put filtered net packing F into the other end of E. Connecting E and G.



Bracket Installation Process

1. Separate D into bracket cover cap and base. (photo **I**)
2. The hook is placed in a predetermined mounting position and marking. (photo **II**)
3. Using electric drill to drill 2 holes in diameter Φ6.5x 30mm depth at the ideal position for bracket D. The holes are used for Plastic Nail Guides Sleeve D1. (Photo **III**)



Photo I


Photo II



Photo III

4. Hammering D1 into the hole. (Photo **IV**)
5. Using Phillips screwdriver to screw D2 (screws) and base D3 into D1 (Plastic Nail Guides Sleeve.) (photo V)
6. Make sure D (screws) are firmly screwed, then put the bracket covor cap be connected with base. (photo V**I**)



photo IV



photo V


photo VI

(3)Installation finished.

Release the stopping water rivet of check valve B.



Usage instruction



Tub Filler Mode

Hand Shower Mode

Maintain and Cleaning

(1)Daily basis: Drying our faucets with a soft cloth immediately after using them.

(2)Spraying our faucets with mild cleaner (PH value = 7), followed by cleaning them with water then drying them with a dried- soft cloth.

(3)Aerator installed at spout of faucet should be taken off and cleaned in case mineral deposits blocked the filtered net; which will decrease the volume of water given.